



RINCK-McILWAINE, INC.

BOX 98 • 89 ARMOUR PLACE, DUMONT, NEW JERSEY 07628 • (201) 384-7600

CABLE ADDRESS: "RIMAC"

PROCEDURE FOR ALIGNING RIMAC'S #95 CALIBRATED SPRING WITH RIMAC SPRING TESTER

1. Calibrated Spring has a black marking on the first ring of spring. This marking indicate's front and top of calibrated spring.
2. When placing calibrated spring in tester make sure spring is placed with marking on top and facing you.
3. Attached to spring is a tag giving you the calibrated compressed height and tension pounds your tester should read.
4. Your reading should be within a plus or minus of 1% of tension pounds shown on tag.